

HUSHPUK® HELPFUL HINTS

Hushpuk® is designed to affix to any location on a longbow, recurve, compound, or crossbow. For maximum adhesion choose a flat, sheltered position.

Thoroughly clean the area to be applied with denatured or isopropyl 91% alcohol, wipe, and let dry. Remove paper backing and apply Hushpuk® to desired location. Simply peel off Hushpuk® and reposition it for optimal performance. If Hushpuk® loses adhesiveness, simply wipe clean with denatured alcohol and let dry. Avoid prolonged exposure to extreme heat and direct sunlight.



Place Hushpuk® on the inside of limbs near the riser.

Place Hushpuk® near the limb pocket or any other point of attachment.



HUSHPUK® HELPFUL HINTS

Our small oblong Hushpuk® in our accessory package fits nicely in the limb in this open limb pocket design in certain bow models.



Place Hushpuks® on sight bars to reduce vibration.



HUSHPUK® HELPFUL HINTS



Small oblong Hushpuks® work great in the honeycomb of most machined risers.

Use 4 oblong Hushpuk® near the limb pockets on any crossbow to help in reduction of noise and vibration.



Place a Hushpuk® near the grip to reduce hand shock.